



**CYCLOPS  
MARINE**  
Dynamic Tuning Guide

<b>Boat Model</b>	<b>Sun Fast 3300</b>
<b>Sensor Position</b>	<b>Forestay</b>
<b>Typical Sensor Used</b>	<b><u>1/2" smarttune</u></b>
<b>Notes</b>	<ul style="list-style-type: none"> <li>• Double Handed Optimised</li> <li>• Ballasted Optimised</li> <li>• J1 at 3-8 knots based on steady breeze</li> <li>• J3 at 17 knots based on a building breeze</li> </ul>

Windspeed (knots)		3-5	6-8	9-10	11-13	14-16	17-19	20+
<b>Optimal</b>	<b>Static/Dock</b>	<b>450</b>	<b>450</b>	<b>550</b>	<b>550</b>	<b>550</b>	<b>550</b>	<b>550</b>
<b>Load (kg)*</b>	<b>Dynamic/Sailing</b>	<b>550</b>	<b>690</b>	<b>1120</b>	<b>1280</b>	<b>1550</b>	<b>1690</b>	<b>1700</b>
<b>Sail Selection</b>		<b>J1/J2</b>	<b>J1/J2</b>	<b>J2</b>	<b>J2</b>	<b>J2</b>	<b>J2/J3</b>	<b>J3</b>

Have questions? Email [info@cyclopsmarine.com](mailto:info@cyclopsmarine.com)